Attention! To work on the W-Tec Eraser Evo chassis you must have excellent mechanic skills. If you do not have these skills do NOT work on this quad!

Adjusting traction rod.



Fig 1: On this picture the bar is shown

It's possible the extend and shorter the traction rod When this bar is shortened the steering mechanism is leaned backwards. This is for a softer tracks.

When this rod is extended the steering mechanism is leaned forwards. This is for a harder tracks or supermotard

Extending / shortening the traction rod



Loosen and remove bolt.



Attention! To work on the W-Tec Eraser Evo chassis you must have excellent mechanic skills. If you do not have these skills do NOT work on this quad!



Turn rod till needed length is reached.



Changes and type failures reserved!
Copy right: W-Tec BV



6) You have to adjust the tow in again. (0.2 - 0.8 cm)

Lengths between A and B H-H (see fig 1.)

Min. 415mm - - - - - - max. 435mm Soft ground - - - - - Hard ground or SM